

Our Lo-Hooks are made from UHMW plastic which is very tough and abrasion resistant. It will not mark your rifle. However, the stainless steel hose clamps can scratch your rifle if they are not installed properly.



Mount the Lo-Hooks on the upper part of the legs of your shooting stool on the side that faces you when in the shooting position. For a clean look, position the screw clamps on the inside of the stool with the screw facing back.



Put the poly cord through the key-hole. Let about 1/2" stick out.



Using both hands, pull the cord all the way down into the narrow section of the key-hole.



Thread the other end of the polycord through the round hole.



And pull it tight.

With your rifle laying in the hooks, take the poly cord over the top of the gun.



Then under the hook engaging the lower slot.



Then back over the top engaging the top slot.



Secure at the handguards.



Secure at the butt stock.



Made with Pride in the USA by
Ray-Vin.Com
1844 Mt Cello Rd
Marianna, FL 32448-5365
www.ray-vin.com
email:rvb@ray-vin.com
1-850-482-7562